19String cable shorting method

- 1.Preparation. The cable must be soldered to the battery pack first, and then plugged into the protection board after checking it correctly. Do not plug the cables into the protection board and then solder them to the battery pack one by one
- 2. When wiring, connect B negative first, then connect the cable, and finally connect C negative to the negative pole of the charger and the load. The battery is always connected to the charger and battery
- 3.Starting from the 17th series of cables on the board, connect the 17th to 19th series to the positive pole of the 17th battery string, the 20th series of cables to the 18th series of battery positive poles, and the 21st series of cables to the total positive pole of the battery (That is, the 19th battery positive pole)

