20String cable shorting method

- 1.Preparation. The cable must be soldered to the battery pack first, and then plugged into the protection board after checking it correctly. Do not plug the cables into the protection board and then solder them to the battery pack one by one
- 2. When wiring, connect B negative first, then connect the cable, and finally connect C negative to the negative pole of the charger and the load. The battery is always con -nected to the charger and battery
- 3. Start from the 1st string of cables on the board, connect the 1st to 21st strings to the positive pole of the corresponding battery pack, and the 21st string of cables to the total positive pole of the battery (that is, the 21st string of battery positive poles)

